K85 Firmware Upgrade Instructions (Snap Version)

Please note that "Snap Tap Mode" has been banned in some games, such as Counter-Strike 2. Please turn off the "Snap" function of the keyboard before entering the game to avoid unnecessary losses.

Unzip the firmware upgrade package. Be sure to unzip it first. This is very important! ! ! ! !

Step 1: It is important to unplug other USB keyboards from the computer, including receivers for other wireless keyboards. Please do this before continuing with the following steps.

Step 2: Connect the K85 keyboard to the USB 3.0 port on your computer, which is usually on the back of the computer.

Step 3: Double-click to open "royuan_tool.exe". If prompted to run iot_driver, click Allow.

[If there is no such prompt, please close (royuan_tool.exe) and perform operation step 3-1. If there is a prompt, skip step 3-1]

resources	2024/8/28 17:25	文件夹	
K85 firmware upgrade instructions, b...	2023/8/22 12:19	Microsoft Edge ...	29 KB
royuan_tool.exe	2024/8/28 17:23	应用程序	22,072 KB

Windows 安全中心

是否要允许公共网络和专用网络访问此应用?

Windows 防火墙已阻止所有公用网络和专用网络上的 iot_driver 的某些功能。

iot_driver

发行者   Shenzhen Rongyuan Technology Co.ltd.

显示更多

允许   取消

Step 3-1: **open the folder (resources), right-click the application file (iot_driver.exe) in the folder [Run as administrator]**

|			
hall_mode.json	2024/7/8 15:53	JSON 文件	1 KB
iot_driver.exe	2024/7/4 14:44	应用程序	6,980 KB
support_config.json	2024/8/16 10:06	JSON 文件	15 KB

Step 4: **open (royuan_tool.exe) and read the existing firmware version of the K85".(This firmware upgrade will upgrade the firmware to version V201,mledVersion:V106)**

ROYUAN UPGRADE TOOL 1.0.12   —   □   ×

USB&MLED UPGRADE(Success:0 Fail:0)

VID:3151 PID:4015 ID:1466 Version: V109 mledVersion:V105

upgrade

Click "upgrade" to upgrade.

Until the last picture shows (Success: 1 Fail: 0)

Step 5: **Uninstall the old K85 software and download the new software from the official website. After opening the software, find "Snap Key" in "Advanced Setting" and bind the keys you need.**

How to turn off the snap function: Select any button that has been set with the snap function and click "Reset" on the right.